
# **EXTENSION CABLE OPTIONS-HOW TO ORDER**

# 6-Pin connector type (D63) used with R-Series Profibus Sensors



#### SENSOR CNNECTOR TYPE (1-3)

DU = Female connector, (straight exit), and PUR bus cable for Profibus sensors with D63 connector
DF = Female connector, (straight exit), and #530040 cable for Profibus sensors with D63 connector
DG = Female connector, (90° exit), and #530040 cable for Profibus sensors with D63 connector
DM = Male connector, (straight exit), and #530040 cable for Profibus sensors with D63 connector

#### CABLE LENGTHS\* (4-7)

 005M
 =
 5M

 015M
 =
 15M


 025M
 =
 25M

 050M
 =
 50M

 100M
 =
 100M

 M
 =
 Cable length

M = Cable length (M)\*




### CABEL TERMINATIO (2 or 3 characters depending on option selected) (8-10)

P0 = Pigtail connection, (no connector)

DFM = Male connector, (Straight exit). For daisy-chain connections of Profibus sensors with D63 connector. Only available with the DF option above.

DGM = Male connector, (90° exit). For daisy-chain connections of Profibus sensors with D63 connector. Only available with the DG option above.

## 5-Pin connector type (D53) used with R-Series Profibus Sensors



## SENSOR CNNECTOR TYPE (1-3)

D53F = Female connector, (straight exit), and violet PVC bus cable (1x2x0.64mm²) for Profibus sensors with D53 connector
D53FV = Female connector, (straight exit), and violet PUR bus cable (1x2x0.64mm²) for Profibus sensors with D53 connector
D53MV = Male connector, (straight exit), and violet PVC bus cable (1x2x0.64mm²) for Profibus sensors with D53 connector
Male connector, (straight exit), and violet PVC bus cable (1x2x0.64mm²) for Profibus sensors with D53 connector
D53MV = Male connector, (straight exit), and violet PVR bus cable (1x2x0.64mm²) for Profibus sensors with D53 connector

## CABLE LENGTHS\* (4-7)

005M = 5M 015M = 15M 025M = 25M 050M = 50M 100M = 100M M = Cable length (M)\* D53F
D53M

#### CABEL TERMINATIO (2 or 3 characters depending on option selected) (8-10)

P0 = Pigtail connection, (no connector)

D53FM = Male connector, (Straight exit). For daisy-chain connections of Profibus sensors with D53 connector. Only available with the DF option above.